ELECTRICAL STARTING SYSTEM

10. Neutral relay

• Disconnect the neutral relay ① coupler (Green/Yellow, Brown, White/Black and Sky blue) from the wireharness.



•Connect the neutral relay coupler (Green/Yellow ③, Brown ④, White/Black ⑤ and Sky blue ⑥) to the Pocket Tester ($\Omega \times 1$) and battery (12V) ②.

Tester (+) Lead→White/Black ⑤ Lead Tester (-) Lead→Sky blue ⑥ Lead Battery (+) Lead→Brown ④ Lead Battery (-) Lead→Green/Yellow ③ Lead



•Check the neutral relay for continuity.

	Good Condition	Bad Condition		
Battery Connected	0	0	×	×
Battery Disconnected	×	0	×	0
: Continuity	x: Discontinuity			

Connect the neutral relay coupler.

CORRECT

INCORRECT

Replace neutral relay.