2004 Honda CR-V LX

2002-04 ENGINES 2.4L 4-Cylinder - CR-V

2002-04 ENGINES

2.4L 4-Cylinder - CR-V

ENGINE ASSEMBLY

ENGINE REMOVAL

Special Tools Required

Front subframe adapter EQS02C000011

NOTE:

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.
- Mark all wiring and hoses to avoid misconnection.

Also, be sure that they do not contact other wiring or hoses, or interfere with other parts.

- 1. Secure the hood in the wide open position (support rod in the lower hole).
- 2. Make sure you have the anti-theft code for the radio, then write down the frequencies for radio's preset buttons.
- 3. Disconnect the negative cable from the battery, then disconnect the positive cable.
- 4. Remove the battery.
- 5. Remove the intake manifold cover.